



**Display on the start page**

If no button is pressed for a few minutes, the display jumps to the main menu. Press **INFO** to go to the start page with the most important plant information.

1. State

- Plant switched on control panel (HMI Basic, Facility, Web)
- Plant switched via external enable (e.g. presence sensor)
- Plant switched on the room control panel (HMI Room)
- Plant switched via the building management system
- Plant switched via the time program
- Plant OFF: Configuration is not complete
- Plant OFF: switched off alarm or emergency stop
- Plant ON: Free cooling, cool-down or overheating protection
- Plant ON: early start before time program (boost)

2. Operating mode

- Off**: Plant OFF
- Start**: Plant is starting up (dampers open, pre heating)
- On**: Plant ON
- Comfort**: Plant ON in comfort mode
- Economy**: Plant ON in economy mode
- Run-on**: Plant follow-up (humidifier/electrical heating coil)

3. Key icon: Display of the logged-in password level

4. Filter alarm: Display of the filter state (depending on the equipment of the plant, the degree of soiling in percent is also displayed).

5. Fan steps: Display of the current fan steps

6. Outside air temp: Display of the current outdoor temperature

7. Valid setpoint: Display of the current valid temperature setpoint

8. Operating mode switch: Switching of the operating mode on the control panel

**ESCAPE button**

Press this button to return to the previous menu item.

### Password entry

- Press **INFO** to access the **main menu**. The topmost entry is the **password enter**. Press **ENTER**.
- A password consists of four numbers. Each number is set separately with the **arrow keys** and confirmed with **ENTER**.  
Enter the user password **1 0 0 0**.  
After entering the password correctly, a key symbol appears at top right of the display.
- Other passwords levels are described in the operating manual.

### Acknowledging alarms (only when alarms are pending)

- Press **ALARM**; the **alarm list detail** appears.
- Then press **ALARM** again; the **alarm list** appears. The topmost entry is **Acknowledge**. Press **ENTER**.
- Select **Execute** with the **arrow keys** and press **ENTER** again. The acknowledgement attempt is started.

### Switch on the plant using the control panel (user password required)

- Use **INFO** to access the **start page**. Select **Operating mode** with the **arrow keys** and press **ENTER**.
- Use the **arrow keys** to mark the required **operating mode** and press **ENTER**.

### Important information!

- The number of plant steps and the availability of the economy mode depend on the configuration of the plant (see operating instructions).
- In economy mode, the plant is operated at a reduced temperature setpoint. See the operating manual for further information.

### Plant information

Use **INFO** to access the **main menu**. Select **Information** with the **arrow keys** and press **ENTER**.  
See the operating manual for a description of the individual items.

### Setting the temperature setpoint (user password required)

- Use **INFO** to access the **main menu**. Select **Setpoints** with the arrow keys and press **ENTER**.
- Go to **Temp control** with the **arrow keys** and press **ENTER**.
- Select **Comfort setpoint** or **Economy setpoint** with the **arrow keys** and press **ENTER**. Now change the value with the **arrow keys** and confirm again with **ENTER**.

### Setting the timer program (user password required)

- Use **INFO** to access the **main menu**. Select **Time program** with the arrow keys and press **ENTER**.
- Recommendation: Set the switching times for **Monday** and copy it to the other days. To do this, select **Monday** with the **arrow keys** and press **ENTER**.
- Time 1** is fixed to **00:00** and cannot be changed. For **Value 1**, **off** is recommended as otherwise the plant starts at 00:00.  
Use the **arrow keys** to go to **Time 2** or **Value 2** and press **ENTER**. Use the arrow keys to send the morning compensation time (e.g. **07:00**) and the operating mode (e.g. **Stage 1**).
- Set the other value/time pairs in the same way. Leave unused switching times at **\*:\***.  
Set a corresponding **value ... to off** as the shut-down time.
- If necessary, copy the time switching catalogue from **Monday** to other days.  
To do this, use the **arrow keys** to go to "Copy schedule" and press **ENTER**. Use the **arrow keys** to select the destination (e.g. **Tues-Fri** for Tuesday to Friday) and confirm with **ENTER**. The time switching catalogue is copied.